

Printer, Fax or Copier Type	Cartridge Part Number	Notes
<b>Brother Colour</b>		
HL3140CW Colour Drum	DR241CL	
HL14140CN Colour Drum	DR-320CL	
HL8250CDN Colour Drum	DR-321CL	
HL4050CN Colour Toner	TN130/TN135 K.C.M.Y.	
HL3040CN Colour Toner	TN230/235 K.C.M.Y.	
HL3140CW Colour Toner	TN241/TN245 K.C.M.Y.	
HL3142CW Colour Toner	TN242/TN246 K.C.M.Y.	
HL14140CN Colour Toner	TN320/TN325 K.C.M.Y.	
HL8250CDN Colour Toner	TN321/TN326 K.C.M.Y.	
HL4570DWMF/FC9970 Colour Toner	TN328 K.C.M.Y.	
MFC1650 Colour Toner	TN329 K.C.M.Y.	
HL8260CDW Colour Toner	TN421/TN423 K.C.M.Y.	
HL9200CDWT Colour Toner	TN900 K.C.M.Y.	
HL9310CDWT Colour Toner	TN910 K.C.M.Y.	
<b>Brother Mono</b>		
HL2240/2250 Series Drum	DR1050	
HL2140 Series Drum	DR2100	
HL2240/2250 Series Drum	DR2200/DR420	
HL2300D Series Drum	DR3200	
HL2210/2510/2710D Series Drum	DR2400	
HL5100 Series Drum	DR3000	
HL5340/5350/5370/5380 Series Drum	DR3200	
HL5450 Series Drum	DR3300	
HL6250/6400 Series Drum	DR3400	
HL1200/1400 Series Drum	DR6000	
HL1110/HL1112 Toner	TN1050	
HL8050 Toner	TN1700	
HL2030/2040 Toner	TN2000	
HL2035/2045 Toner	TN2005	
HL2130/CP7055 Toner	TN2010	
HL2140/2150/2170 Series Toner	TN2110/TN2120	
HL2240/2250 Series Toner	TN2210/TN2220	
HL2300D Series Toner	TN2310/TN2320	
HL2310/2510/2710D Series Toner	TN2410/TN2420	
HL5240/5250 Series Toner	TN3130/TN3170	
HL5340/5350/5370/5380 Series Toner	TN3230/TN3280	
HL5450 Series Toner	TN3330/TN3380	
HL5450 Series Hi-Cap Toner	TN3390	
HL6250/6400 Series Toner	TN3430/TN3480	
HL6250/6400 Series Hi-Cap Toner	TN3512/TN3520	
HL1200/1400 Series Toner	TN6300/TN6600	
<b>Canon Colour</b>		
LBP-710/712 Colour Toner	CRG-040 BCMY	
LBP-710/712 Colour Toner	CRG-040H BCMY	
LBP-5000/5100 Colour Toner	CRG-707 BCMY	
LBP-5300/MF-9170/9220/9280 Colour Toner	CRG-711 BCMY	
LBP-5050/MF8030/40/50/80 Colour Toner	CRG-716 BCMY	
LBP-7200/7660/MF-8330/40/50 Colour Toner	CRG-718 BCMY	
LBP-7750C Colour Toner	CRG-723 BCMY	
LBP-7100CN Colour Toner	CRG-731 BCMY	
LBP-7780C Colour Toner	CRG-732 BCMY	
LBP-9100C/9500C/9600C Colour Toner	CRG-322 BCMY	
LBP-9100C/9500C/9600C Colour Toner	CRG-322H BCMY	
iR C1225 Drum	C-EXV034 Drum	
iR C5045/C5051 Drum	C-EXV28 Drum	
iR C5030 Drum	C-EXV29 Drum	
iR C7055/C7065 Colour Toner	C-EXV31 BCMY	
iR C2520/2525/2530 Drum	C-EXV34 Drum	
iR C7280 Colour Toner	C-EXV45 BCMY	
iR C250 Colour Toner	C-EXV47 BCMY	
iR C250/350 Drum	C-EXV47 Drum	
iR C1325/C1335 Colour Toner	C-EXV48 BCMY	
iR C3325 Colour Toner	C-EXV49 BCMY	
iR C325/3330 Drum	C-EXV49 Drum	
iR C5335/5540/5540/5560 Colour Toner	C-EXV51 BCMY	
iR C5335/5540/5540/5560 Drum	C-EXV51 Drum	
<b>Canon Mono</b>		
FC-200 Series Copier	E30	
iR1133	C-EXV40	
LBP-1210	EP-25	
LBP-3200	EP-27	
FilePrinter 400	FP-400	
i-SENSYS LBP-6000/Imagerunner 285	CRG-725	
LBP-1610/LBP-1810/LBP-910	EP-62	
LBP-1760/LBP-1760a	EP-52	
LBP-1910/LBP-3260	EP-72	
LBP-2460	EP-W	
LBP-2900/LBP-3000/L100/Fax L120	CRG-103/303/703	
LBP-3010/LBP-300	CRG-312/712	
LBP-3250	CRG-313/713	
LBP-321X	CRG-041	
LBP-321X	CRG-041H	
LBP-3300/LBP-3360	CRG-108/308/508/708	
LBP-3300/LBP-3360	CRG-108H/308H/508H/708H	
LBP-3310/LBP-3370	CRG-715H	
LBP-3410/LBP-3460	CRG-310/510/710	
LBP-3410/LBP-3460	CRG-310H/510H/710H	
LBP-3500/LBP-3900/LBP-3950	CRG-509	
LBP-6200/Fax L-150	CRG-726/728	
LBP-6300/LBP-6650/MF-5840	CRG-719	
LBP-6300/LBP-6650/MF-5840	CRG-719H	
LBP-6700/LBP-6750D/LBP-6780X	CRG-524/724	
LBP-6700/LBP-6750D/LBP-6780X	CRG-524H/724H	
LBP-9610	CRG-527	
iR 2200/2800/3300/3320 Drum	C-EXV3 Drum	
iR 1600/1610/2000/2010 Drum	C-EXV5 Drum	
iR 2016/2020/2318/2320/2420/2422 Drum	C-EXV14 Drum	
iR 2018/2022/2025/2030 Drum	C-EXV23 Drum	
iR 6055/6075 Toner	C-EXV36	
iR 1730 Drum	C-EXV37 Drum	
iR 1435 Toner	C-EXV50 Toner	
iR 1435 Drum	C-EXV50 Drum	
<b>Dell Colour</b>		
1250C Colour Toners	DL3K9XM/PDVTW/CMR3C/5M1/YR	
3000 Photocopy	N86	
3110/3115CN Colour Toners	NF555/MF790/RF012	
3110/3115CN Hi-Cap Colour Toner	PF029/RF013/NF556	
3130CN Hi-Cap Colour Toners	H515C/H514C/H513C	
5130C Colour Toners	F942P/F901F/G450R/G439R/P946P	
7130C Colour Toners	3GD10/4C8RP/31PH1/61NH	
7765C Colour Toners	J6DTHF5Y6V/8N8J/6YJGD	
C2660/C2665 Drum	593-BBEJ.59J78	
C2660/C2665 Colour Toners	67H2T3070P/TW3NN/KD80W	
C3780/C3785 Colour Toners	4CH17/P/M/NEY/NC5/W6/M/8/W2	
H8258/25 Colour Toners	NCH0D/WG41D/042T1/2RFOR	

Printer, Fax or Copier Type	Cartridge Part Number	Notes
<b>Dell Mono</b>		
113X (No Starters)	3J11D/2MMJP	
B1160 (No Starters)	HF44N	
B126X	DRYXV/G9W85	
B2375 Standard & Hi-Cap	N2XPF/C7D6F/8P1TH	
B2350/3460/4365	HJODH1XCH/C3NTP11V77/MCSJ	
B5460DN	GDFKW/71MXV/JNC45/03YU	
P1500	7Y608/7Y610	
1700 Toner	D4283/N3769/J3730/J3815	
1720 Toner	MV558/GF332/PP380	
1615	RF223/NF465/PF656/PF658	
2330 Toner	PK941/PK942/PK937	
2335	CR963/HX756	
2355	YTVTC	
5200/5300	N0893/R0136/R2925/N2157/K2885/M2925	
5210N/5310N	UD314/RD307/HD767/TD381/G3531/PD974	
5230/5320/5350	D5247/F3627/2KMVD/F361T/Y902/RYPMDR	
<b>Epson Colour</b>		
AC1100 Photoconductor	S051104	
C1600 Colour Toner	S0510557/558/559/560	
C1700 Colour Toner	S050611-14/S050669-72	
C3800 Colour Toner	1124/1125/1126/1127	
<b>Epson Mono</b>		
AL - M200/AL-MX200 Toner	S050709	
AL-M300/AL-MX300 Toner	S050689/690/691	
AL-M300/AL-MX300 Photoconductor	S051228	
AL-M400 Toner	S050698/699	
AL-M8100	S050762	
EPL-N3000	S051111	
M2000 Series Toner	S050435/36/37/38	
M2300/M2400 Series Toner	S050582/83/84/85	
M4000	S0501170	
N4000	S051073	
<b>HP Colour</b> No Introductory/Starter Toners		
Colour LaserJet 2600/1600/CM1015 Colour Toner	C6500A/C6601A/C6702A/C6803A/124A	
Colour LaserJet 3500 Colour Toner	C2670A/C2671A/C2672A/C2673A/308/309A	
Colour LaserJet 3600 Colour Toner	C6470A/C6471A/C6472A/C6473A/501/502A	
Colour LaserJet 3700 Colour Toner	C2670A/C2681A/C2682A/C2683A/308/311A	
Colour LaserJet 3800 Colour Toner	Q7581A/Q7582A/Q7583A/503A	
Colour LaserJet 4700 Colour Toner	C9590A/C9591A/C9592A/C9593A/643A	
Colour LaserJet 4730 Colour Toner	Q6460A/Q6461A/Q6462A/Q6463A/644A	
Colour LaserJet 5500 Colour Toner	C9730A/C9731A/9732A/9733A/645A	
Colour LaserJet CM1300/1210 Colour Toner	CE540A/CB541A/CB542A/CB543A/125A	
Colour LaserJet CM1415/CP1525 Colour Toner	CE320A/CE321A/CE322A/CE323A/128A	
Colour LaserJet CM4540 Black Toner	CE264X/648X	
Colour LaserJet CM4540 Colour Toner	CF031A/CF032A/CF033A/646A	
Colour LaserJet CP1025 Colour Toner	CE310A/CE311A/CE312A/CE313A/126A	
Colour LaserJet CP2025/CM2320 Colour Toner	CC530A/CC531A/CC532A/CC533A/304A	
Colour LaserJet CP3525/3530 Black Toner Hi-Cap	CE250X/504X	
Colour LaserJet CP3525/3530 Colour Toner	CE250A/CE251A/CE252A/CE253A/504A	
Colour LaserJet CP4025/4030 Colour Toner	CB400A/CB401A/CB402A/CB403A/642A	
Colour LaserJet CP4025/4525 Black Toner Hi-Cap	CE260X/648X	
Colour LaserJet CP4025/4525 Colour Toner	CE260A/CE261A/CE262A/CE263A/648A	
Colour LaserJet CP5225 Colour Toner	CE740A/CE741A/CE742A/CE743A/307A	
Colour LaserJet CP5225 Colour Toner	previously recycled CE741A/307A	
Colour LaserJet CP5225 Black Toner	CE270A/650A	
Colour LaserJet CP5520 Colour Toner	CE271A/CE272A/CE273A/650A	
Colour LaserJet CP5520 Colour Toner	previously recycled CE271A/650A	
Colour LaserJet M176 Colour Toner	CF350A/CF351A/CF352A/CF353A/130A	
Colour LaserJet M180/181 Colour Toner	CF530A/CF531A/CF532A/CF533A/205A	
Colour LaserJet M52 Colour Toner	CF400A/CF401A/CF402A/CF403A/201A	
Colour LaserJet M252 Hi-Cap Colour Toner	CF400X/CF401X/CF402X/CF403X/201X	
Colour LaserJet M254/280/281 Colour Toner	CF540A/CF541A/CF542A/CF543A/203A	
Colour LaserJet M254/280/281 Hi-Cap Colour Toner	CF540X/CF541X/CF542X/CF543X/203X	
Colour LaserJet M452 Colour Toner	CF410A/CF411A/CF412A/CF413A/410A	
Colour LaserJet M452 Hi-Cap Black Toner	CF410/410X	
Colour LaserJet M452 Hi-Cap Colour Toner	CF411X/CF412X/CF413X/410X	
Colour LaserJet M476 Hi-Cap Black Toner	CF380X/312X	
Colour LaserJet M476 Colour Toner	CF380A/CF381A/CF382A/CF383A/312A	
Colour LaserJet M51 Hi-Cap Black Toner	CE400X/507X	
Colour LaserJet M51 Colour Toner	CE400A/CE401A/CE402A/CE403A/507A	
Colour LaserJet M52 Black Toner	CF360A/508A	
Colour LaserJet M52 Colour Toner	CF361A/CF362A/CF363A/508A	
Colour LaserJet M52 Hi-Cap Black Toner	CF360X/508X	
Colour LaserJet M52 Hi-Cap Colour Toner	CF361X/CF362X/CF363X/508X	
Colour LaserJet M51/M680 Black Toner	CF330A/652A	
Colour LaserJet M51 Hi-Cap Black Toner	CF330X/654X	
Colour LaserJet M51 Colour Toner	CF331A/CF332A/CF333A/654A	
Colour LaserJet M52/653/M681/682 Black Toner	CF450A/655A	
Colour LaserJet M52/653/M681/682 Colour Toner	CF451A/CF452A/CF453A/655A	
Colour LaserJet M52/653 Hi-Cap Black Toner	CF460X/656X	
Colour LaserJet M52/653 Hi-Cap Colour Toner	CF461X/CF462X/CF463X/656X	
Colour LaserJet M680 Hi-Cap Black Toner	CF320X/653X	
Colour LaserJet M680 Colour Toner	CF321A/CF322A/CF323A/653A	
Colour LaserJet M61/682 Hi-Cap Black Toner	CF470X/657X	
Colour LaserJet M61/682 Hi-Cap Colour Toner	CF471X/CF472X/CF473X/657X	
Colour LaserJet M775 Black Toner	CE340A/651A	
Colour LaserJet M775 Colour Toner	CE341A/CE342A/CE343A/651A	
Colour LaserJet M855 Colour Toner	CF310A/CF311A/CF312A/CF313A/826A	
Colour LaserJet M890 Colour Toner	CF300A/CF301A/CF302A/CF303A/827A	
Colour LaserJet Pro 200 Hi-Cap Black Toner	CF210X/131X	
Colour LaserJet Pro 200 Colour Toner	CF210A/CF211A/CF212A/CF213A/131A	
Colour LaserJet Pro 300/400 Hi-Cap Black Toner	CE410X/305X	
Colour LaserJet Pro 300/400 Colour Toner	GE410A/CE411A/CE412A/CE413A/305A	
<b>HP Mono</b> No Introductory/Starter Toners		
LaserJet 1200	C7115A	
LaserJet 1200	C7115X	
LaserJet 1010/1215/18/20/22/32/3015/20/30	Q2612A	
LaserJet 1160/1320	Q5949A	
LaserJet 1300	Q2613X	
LaserJet 1320	Q5949X	
LaserJet 2300	Q2610A	
LaserJet 2400/10/20/30	Q6511A	
LaserJet 2400/10/20/30	Q6511X	
LaserJet 4000/4050	C4127A	
LaserJet 4000/4050	C4127X	
LaserJet 4100	C8061A	
LaserJet 4100	C8061X	

Printer, Fax or Copier Type	Cartridge Part Number	Notes
<b>HPE/Alonga continued</b>		
LaserJet 4200	O1338A	
LaserJet 4200	previously recycled O1338A	
LaserJet 4240/4250/4350	O5942A	
LaserJet 4240/4250/4350	O5942X	
LaserJet 4300	O1338A	
LaserJet 4345/MF4345	O5945A	
LaserJet 5000/5100	C4129X	
LaserJet 5200	O7516A	
LaserJet 5SI/8000	C3909A.X	
LaserJet 8100/8150	C4182X	
LaserJet 9000/9040/9050	C8543X	
LaserJet M3027/M3035/P3005	O7551X	
LaserJet M5025	O7570A	
LaserJet M4555mp	CE390A	
LaserJet M4555mp	CE390X	
LaserJet M630mp	CF281A	
LaserJet M630mp	CF281X	
LaserJet P1005/P1006	CB435A	
LaserJet P1505/P1505n	CB436A	
LaserJet P1102	CE285A	
LaserJet Pro P1606N	CE278A	
LaserJet P2015/P2014	O7553X	
LaserJet P2035/P2055	CE505A	
LaserJet P2035/P2055	CE505X	
LaserJet P3015 Series	CE255A	
LaserJet P3015 Series	CE255X	
LaserJet P4014/P4015/P4515	CC364A	
LaserJet P4015/P4515	CC364X	
LaserJet P4015/P4515	previously recycled CC364X	
LaserJet Enterprise 700 M725	CF214A	
LaserJet Enterprise 700 M725	CF214X	
LaserJet Enterprise M506/520	CF287A	
LaserJet Enterprise M506/520	CF287X	
LaserJet Enterprise M607	CF237A	
LaserJet Enterprise M607/608	CF237X	
LaserJet Enterprise M607/608	CF237Y	
LaserJet Enterprise M830z/M806x/M806dn	CF325X	
LaserJet Pro 400	CF280A	
LaserJet Pro 400	CF280X	
LaserJet Pro M102/104/130/132	CF217A	
LaserJet Pro M102/104/130/132	CF219A	
LaserJet Pro M203/227	CF230A	
LaserJet Pro M203/227	CF230X	
LaserJet Pro M203/227 Drum	CF232A	
LaserJet Pro M402/426	CF226A	
LaserJet Pro M402/426	CF226X	
LaserJet Pro M403	CF228A	
LaserJet Pro M403	CF228X	
LaserJet Pro MFP M125/M127	CF283A	
LaserJet Pro MFP M201/M205	CF283X	
LaserJet MFP M436n	CF256A	
LaserJet MFP M436n	CF256X	
LaserJet MFP M436n	CF257A	
<b>ISM/Imaging</b>		
Infoprint 1145	28P1882	
Infoprint 1312	75P4686	
Infoprint 1332	75P4301/4302/4303	
Infoprint 1412 Toner	75P5708/5709/5710/5711	
Infoprint 1570 Toner	39V0542/0543/0544/0545	
Infoprint 1540/1585 Toner	75P5877	
Infoprint 1612 Toner	39V1638/1641/1642	
Infoprint 1811 Toner	39V3202/3203/3204	
Infoprint 1832/1852/1872	39V2511/2513/2514/2515	
Infoprint 1930/1940 Toner	39V3713/3715/3716/3717	
<b>Konica Minolta Colour</b>		
BizHub C200/C220	DR-311	
BizHub C454/C554	DR-512	
BizHub C203/C253 Colour Toner	TN213 K/C/M/Y	
BizHub C220 Colour Toner	TN216 K/C/M/Y	
BizHub C221 Colour Toner	TN321 K/C/M/Y	
BizHub C360 Colour Toner	TN319 K/C/M/Y	
BizHub C454/C554 Colour Toner	TN512 K/C/M/Y	
Magicolor 1600W Colour Toner	AV03***	
Magicolor 2400/2500 Colour Toner	1710587-00	
Magicolor 2400 Drum	Drum (4059)	
<b>Konica Minolta Mono</b>		
BizHub 3320/4020/3300P/4700P	TNP34/TNP36/TNP37/TNP40/TNP41/TNP44	
PagePro 1400W Toner	9J04202	
PagePro 1400W Drum Unit	4519-401	
<b>Kyocera Colour</b>		
C1020 Colour Toner	TK150 K/C/M/Y	
CS100DN Colour Toner	TK540 K/C/M/Y	
CS300N Colour Toner	TK560 K/C/M/Y	
FS-C5150 Colour Toner	TK580 K/C/M/Y	
FS-C2025MFP Colour Toner	TK590 K/C/M/Y	
TASKalfa 250ci Colour Toner	TK865 K/C/M/Y	
FS-C8025MFP Colour Toner	TK895 K/C/M/Y	
M6030dn Colour Toner	TK5140 K/C/M/Y	
M6035dn Colour Toner	TK5150 K/C/M/Y	
P7040cdn Colour Toner	TK5160 K/C/M/Y	
TASKalfa 306ci Colour Toner	TK5195 K/C/M/Y	
TASKalfa 356ci Colour Toner	TK5205 K/C/M/Y	
TASKalfa 35406ci Colour Toner	TK5215 K/C/M/Y	
TASKalfa 5032/6032 Colour Toner	TK5215 K/C/M/Y	
Ecosys M5521/P5021 Colour Toner	TK5230 K/C/M/Y	
Ecosys M5 Series Colour Toner	TK5240 K/C/M/Y	
Ecosys M6230/6630/P6230 Colour Toner	TK5270 K/C/M/Y	
Ecosys M6235/6635/P6235 Colour Toner	TK5280 K/C/M/Y	
Ecosys P7240 Colour Toner	TK5290 K/C/M/Y	
<b>Kyocera Mono</b>		
FS-720/820/9201 Toner	TK110	
FS-1300D/7200P Toner	TK130	
FS-1110/4000P Toner	TK140	
FS-1120 Toner	TK160	
FS-1320D Toner	TK170	
FS-2000DN Toner	TK310	
FS-4000DN Toner	TK320	
FS-2020 Toner	TK340	
FS-3920N Toner	TK350	
FS-4020DN Toner	TK360	
KM-2540 Toner	TK675	
KM-1650 Drum	MK-410 Drum	
FS-1120 Toner	TK1110	
FS-1041 Toner	TK1115	
FS-1125 Toner	TK1120	
FS-1061DN Toner	TK1125	
FS-1130MFP Toner	TK1130	
FS-1035MFP Toner	TK1140	

Printer, Fax or Copier Type	Cartridge Part Number	Notes
<b>Kyocera Mono (contin)</b>		
Ecosys P2040 Toner		TK1160
Ecosys M2040/2540/2640 Toner		TK1170
FS-2100N/DN Toner		TK3100
P3045/50/55/60 Toner		TK3160
P3050/TK3170 Toner		TK3170
P3055dn Toner		TK3190
<b>Lexmark Colour</b>		
C2132	24B6008/6009/6010/6011	
C925 Colour Toner	C925H2*G	
C930/935 Colour Toner	C930H2*G	
C950 Colour Toner	C950H2*G	
C500 Colour Toner	C500***	
C510 Colour Toner	20K050*/20K140*	
C522/C524/C530/C534 Colour Toner	C5220**/C5222**	
C540/C544/X544	C540***/C544***/X544***	
C6160	24B5995/5996/5997/5998	
C737/736/738	C734A**G	
C736/738 High Capacity	C736H**G	
CS310/CS410/CS510	700*/702**	
CS/CX317/CS417/CS517	800*/802**	
CS/CX417/CX517	71B20*0	
CS720/725	71B2H*0/71B2XK0/71B0X10	
CX720/725	74C****	
CX820/860	84C****	
CX820/860	72K****	
C780/782	82K****	
C792/C796/X792	C780**/C782**	
X940/945 Colour Toner	C792***/C796***/X792***	
X950 Colour Toner	X945X2*G	
XC21000/2130/2132 Colour Toner	X950X2*G	
XC2235 Colour Toner	24B6008/6009/6010/6011	
XC2240 Colour Toner	24B7178/7179/7180/7181	
XC4130/4140/4150 Colour Toner	24B7182/7183/7184/7185	
XC4240 Colour Toner	24B6717/6718/6719/6720	
XC6100/6152 Colour Toner	24B7182/7183/7184/7185	
XC8160 Colour Toner	24B6508/6509/6510/6511	
XS748 Colour Toner	24B6512/6513/6514/6515	
XS795/798 Colour Toner	24b5700/5701/5702/5703	
XS950 Colour Toner	24B6018/19/22/22	
	22Z008/009/0010/0011	
<b>Lexmark Mono</b>		
E230/232 Toner	12A83**/84**	
E250 Toner	E250A11E/E250A21E	
E260/360/460 Standard Toner	E260A11E/E260A21E	
E320/E322 Toner	08A0475/08A0476/08A0477/08A0478	
E321/E323 Toner	12A7300/12A7305/12A7400/12A7405	
E330/340 Toner	12A8*0/240*6/E/340*6/E	
E350/352 Toner	E352H11E/E352H21E	
E360/460 High Yield Toner	E360H11E/E360H21E	
E450 Toner	E450A11E/A21E/H11E/H21E	
E460 Extra High Yield Toner	E460X11E/E460X21E	
Optra N	1382140	
Optra S / T	1382*2*/12A0150/12A514*	
M1140/3140/3240/5140/5240 Series Toner	24B6035	
M3150/5150 Series Toner	24B6186	
MS310/410/510/610/ Series Toner	500UA/502*	
MS321/421/521/621/721/821 Series Toner	56F3000/3H00/0HA0	
MS4175/1761/7617/8614/1751/7617 Series Toner	51B***0	
MS710/810/820 Series Toner	620XA/622*	
MX310/410/510/610 Series Toner	500UA/502*	
MX321/421/521/621/721/821 Series Toner	56F3000/3H00/0HA0	
MX710/810 Toner	56F3000/3H00/0HA0	
TI420	620XA/622*	
T430/T430D/T430DN	12A7310/7315/7410/7415	
T520/T620 Toner	0012A8425/12A8425/012A8425	
T630/632/634/X630/X632	12A6835/6730/12A6760/6860	
T640/642/644 Standard Yield	12A7360/7362/7460/7462	
T640/642/644 High Yield	64016SE/64036SE	
T640/642/644	64016HE/64036HE	
T650/652/654/656 Standard Yield	previously recycled 64016SE/HE/64036SE/HE	
T650/652/654/656 High Yield	650A11E/650A21E	
T654/656 Extra High Yield	650H11E/650H21E	
W620	654X11A/654X21A	
W840 Toner	12B0090	
W840 Photoconductor	W84020H	
X363 Toner Standard Yield	W84030H	
X363 Toner High Yield	X363A11GX/X363A21G	
X463/X464/X466	X363H11GX/X363H21G	
X644 Extra High Yield	X463H11GX/X463H21G	
X642e/644 High Yield	X644X11E/X644X21E	
X642e/644 Standard Yield	X644H11E/X644H21E	
X642e/644	X644A11E/X644A21E	
X644/X642	previously recycled X644***	
X651/652/654/656/658 Standard Yield	previously recycled X644X11E/X644X21E	
X651/652/654/656/658 High Yield	X651A11E/X651A21E	
X654/656/658 Extra High Yield	X651H11E/X651H21E	
X860/862/864 Toner	X654X11E/X654X21E	
XM11wx/12wx/31wx/32wx/51wx/53xx Series Toner	X860H21G	
XM71wx/73xx Series Toner	24B6015	
X860/862/864 Toner	24B6020	
	X860H21G	
<b>Nashuatec Mono</b>		
P7325N		DT51BLK
<b>OKI Colour</b>		
KX MB2000 Drum		KXFAD412X
C110/C130 Colour Toner	44250717/18/19/21/22/23/24	
C310 Colour Toner (No Intro)	44469803/04/05/06	
C510 Colour Toner (No Intro)	44469722/23/24	
C710/C711 Colour Toner (No Intro)	44318608/07/06/05	
C822/C822n Colour Toner (No Intro)	44844613/14/15/16	
C822/C831/C841 Colour Toner (No Intro)	44844505/06/07/08	
<b>OKI Mono</b>		
B2500/2520/2540 Toner	09004447/4391*	
B6200/B6300	09004078/79*	
B6500	09004461/62*	
B410 Drum	43979002	
B411/431/441/451 Drum	44574302/44574307	
B4400/B4600 Drum	43901902	
B710	01273001	
B721/731	45488802/45439002	
<b>Panasonic Mono</b>		
UF585/595	UG3350/3380	
KX MB2000 Toner	KXFA1411X	
KX MB2000 Drum	KXFAD412X	
<b>Ricoh Colour</b>		
Alicio SP C220E Colour	40605*/40614*	
Alicio SP C240/250 Colour	407543*/4445/46*	
Alicio SP C310E Colour	406479/80/81/82	
Alicio SP C410 Photoconductor	420243	
Alicio SP C410 Toner	888312/13/14/15*	

Printer, Fax or Copier Type	Cartridge Part Number	Notes
<b>Types 1027 Photoconductor</b>		
Type 1250	430351	
Type 1027 Photoconductor	412271	
Alicio SP1000	413196	
Alicio SP3400/SP3500	406515/406523	
Alicio MP2000	885094	
AP400/AP410/Type 220	400943	
AP2600	400618	
MPC2500/3500/4500 Photoconductor	0	
Ricoh MP4054SP Toner	4054	
SP100E/SP112	407166	
SP311X/XE	932930/905222	
SP5200	402877	
SP200 Series / SP201LE	207254/207255	
SP3600	407340/407323	
SP4100	402810/407649/403180	
SP4510 Toner	407318	
SP4510 Drum	407324	
SP4520	841887	
SP6300N	406649	
SP6400/6430 Toner	407507/407510	
SP6400/6430 Drum	407511	
<b>Samsung Colour</b>		
CLP-310 Drum	CLT-R409	
CLP-310/315 Colour (no starters)	CLT-4092	
CLP-320 Drum	CLT-R407	
CLP-320 Colour Toner (no starters)	CLT-4072	
CLP-360 Drum	CLT-R406	
CLP-360/365 Colour Toner (no starters)	CLT-406	
CLP-410/415 Colour Toner (no starters)	CLT-504	
CLP-510 Colour Toner (no starters)	CLT-510	
CLP-620/670 Toner (no starters)	CLT-5082L	
CLP-680 High Cap Black Toner (no starters)	CLT-K506	
CLP-680 Colour Toner (no starters)	CLT-506	
CLP-770 Colour Toner (no starters)	CLT-6092	
CLX-8385 Colour Toner (No Black)	CLT-8385	
CLX-8640 Colour Toner (No Black)	CLT-659	
CLX-8640 Drum	CLT-R659	
CLX-9201NA Colour Toner (no starters)	CLT-809S	
CLX-9201NA Drum	CLT-R809	
ProXpress C 4010/4060 Colour Toner (no starters)	CLT-603	
SL-C430W/C460W Colour Toner (no starters)	CLT-404	
SL-C2620DW/C2670FW Colour Toner (no starters)	CLT-505	
SL-X7400/7500/7600 Colour Toner (No Black)	CLT-806	
X4220S/4300 Colour Toner (No Black)	CLT-808	
<b>Samsung Mono</b>		
ML-1660 (No starters)	MLT-D1042	
ML-2160 (No Starters)	MLT-D101S	
ML-2580 (No starters)	MLT-D1052S/L	
ML-2950 (No Starters)	ML-2950S/L	
ML-3050	ML-3050	
ML-3310/ML-3710 Hi-Cap & Standard Cap	MLT-D205E/L/S	
ML-3750ND	MLT-D305L	
ML-4510 Toner	MLT-D307E/L/S	
ML-4510 Drum	MLT-R307	
ML-4550	MLT-D4550	
ML-5510 Toner	MLT-D309E/L/S	
ML-5510 Drum	MLT-R309	
SL-M2020	MLT-D111S	
SL-M2675 Toner	MLT-D116S/L	
SL-M2675 Drum	R116	
SL-M3325 Toner	MLT-D204S/L	
SL-M3325 Drum	MLT-R204	
SL-M3320 Toner (No Starters)	MLT-D203S/E/L	
SL-M3320 Ultra Hi-Capacity	MLT-D203U	
SL-M4030 Toner	MLT-D201S/L	
SL-M4370/M5370 Toner	MLT-D358S/L	
SL-M4370/M5370 Drum	MLT-R358	
SL-M4530 Toner	MLT-D304S/L	
SL-M4530 Drum	MLT-R304	
SL-M4580 Toner	MLT-D303E	
SL-M4580 Drum	MLT-R303	
SCX-5330	SCX-5330B	
SCX-5530	SCX-5530	
SCX-6555 Toner	SCX-6555	
SCX-6555 Drum	SCX-6555	
SCX-8030/8040	MLT-D606/607S	
<b>Sharp Mono</b>		
AL-10000	AL-110DR Drum	
AL-2041	AL-214 Toner	
AM300/400	AM-300C	
<b>Ufax Colour</b>		
CDC5520/5525	65251101*	
<b>Xerox Colour</b>		
Phaser 6010 Colour Toner	106R01627/28/29/30	
Phaser 6120 Photoconductor	108R00691	
Phaser 6121mp Colour Toner	106R01463-69	
Phaser 6180 Colour Toner	113R719/20/21/22	
Phaser 6180 Hi-Cap Colour Toner	113R723/24/25/26	
Phaser 6280 Colour Toner	106R01388/89/90/92/93/94/95	
Phaser 6510 Colour Toner	106R03473/74/75/76/77/78/79/80	
Phaser 6600 Colour Toner	106R02229/30/31/32/45/46/47/48	
Phaser 6600/6605 Photoconductor	108R01121	
Phaser 7100 Colour Toner	106R02599/02600/2601/2605	
Phaser 7120 Colour Toner	106R02599/02600/2601/2605	
Phaser 7120 Photoconductor	013R00657/60/69/68	
Phaser 7500 Colour Toner	106R01433/34/35/36/37/38/39	
Phaser 7525 Colour Toner	06R1509/10/11/12/13/14/15/16	
Phaser 7760 Colour Toner	106R01160/1161/1162/1163	
Phaser 7800 Colour Toner	106R01563/64/65/66/67/68/69	
VersaLink C400/405 Colour Toner	VersaLink C400/405 Colour Toner	
VersaLink C500/505 Colour Toner	106R03862/70/71/72/73/74/75/76	
VersaLink C7000 Series Colour Toner	106R0373/38/39/40/41/42/43/44	
Work Centre 6655 Colour Toner	106R02744/02845/02846/02847	
Work Centre 7132/7132/7242	006R01317/01263/64/65/67/68/69	
Work Centre 7228/7328/C2128 Colour Toner	6R01175/1176/1177/1178	
Work Centre 7425/7428/7435 Colour Toner	006R01395/1396/1397/1398	
Work Centre 7525/7530/7535/7545/7556 Photoconductor	013R00662	
<b>Xerox Mono</b>		
DocuPrint N32/N40	113R184	
Phaser 3020/Workcentre 3025	106R02773/03048	
Phaser 3052/3260/Workcentre 3215	106R02775/02777/02778	
Phaser 3100mp	106R01378	
Phaser 3320	106R02305/106R02307	
Phaser 3330/3345/Workcentre 3345	106R03620/3622/3624	
Phaser 3600	106R01370/71	
Phaser 3610 Toner	106R02720/22/31	
Phaser 3635	108R00792/93/95	
Phaser 4500	113R956	
Phaser 4510	113R711/712/715	
Phaser 4600 Toner	106R01532/1533/1535	
Phaser 4600 Photoconductor	113R762	
Phaser 5500/5550 Toner	113R00668/106R01294/6R01184	
Phaser 5500/5550 Photoconductor	13R00589	
Phaser 5500/5550 Toner	113R00668/106R01294/6R01184	
Phaser 5500/5550 Photoconductor	13R00589	
VersaLink B4000/B405	10603580/3582/3584	
VersaLink B600/B605/B610/B615	106R03940/3942/3944/4003	
Workcentre Pe220	13R00621	
Workcentre 3655	106R02736/02738/02740/02742	
Workcentre 5222/5225/5230 Toner	106R01306	

Printer, Fax or Copier Type	Cartridge Part Number	Notes
<b>USED FUSER UNITS</b>		
<b>Printer Type</b>		
HP LaserJet 4200 Fuser Unit	RM1-0014-000CN	
HP LaserJet 4250/4350 Fuser Unit	RM1-1083-000CN	
HP LaserJet 4300 Fuser Unit	RM1-0102-000CN	
HP LaserJet 4345 Fuser Unit	RM1-1043-000CN	
HP LaserJet 5200 Fuser Unit	RM1-2524-000CN	
HP LaserJet 9000 Fuser Unit	RG5-5751-000CN	
HP LaserJet M4555 Fuser Unit	RM1-7397-000CN	
HP LaserJet M5025 Fuser Unit	RM1-3008-000CN	
HP LaserJet M600 Fuser Unit	RM1-8396-000CN	
HP LaserJet M604/605/606 Fuser Unit	RM2-6342-000CN	
HP LaserJet M806/830 Fuser Unit	RM1-9814-000CN	
HP LaserJet P4014/P4015 Fuser Unit	RM1-4579-000CN	
HP Colour LaserJet 3800 Fuser Unit	RM1-2764-000CN	
HP Colour LaserJet 4700 Fuser Unit	RM1-1734-000CN	
HP Colour LaserJet 4730 Fuser Unit	RM1-3146-000CN	
HP Colour LaserJet 5500/5550 Fuser Unit	RG5-6701-000CN	
HP Colour LaserJet CP3525 Fuser Unit	RM1-4995-000CN	
HP Colour LaserJet CP4525 Fuser Unit	RM1-5606-000CN	
HP Colour LaserJet CP5225 Fuser Unit	RM1-6095-000CN	
HP Colour LaserJet CP5520/5525 Fuser Unit	RM1-6082-000CN	
HP Colour LaserJet M775 Fuser Unit	RM1-9373-000CN	
HP Colour LaserJet M800 Fuser Unit	RM2-5013-000CN	
HP Colour LaserJet M880 Fuser Unit	RM2-5028-000CN	
Lexmark T640 Fuser Unit	40X2590	
Lexmark T650 Fuser Unit	40X1871	
Ricoh Aficio 2035/2045 Fusing Unit	Adoris C3	
Ricoh Aficio 3035/3045 Fusing Unit	Adoris C4	
Ricoh Aficio 3228/3235/3245 Fusing Unit	Jupiter C2	
Ricoh MP3500/MP4500 Fusing Unit	Adoris C4.5	
Ricoh MPC2030/MPC2530 Fusing Unit	Diana C1	
Ricoh MPC2500/MPC3000 Fusing Unit	Athena C1	
Ricoh MPC2800/MPC3300 Fusing Unit	Athena C2	
Ricoh MPC3001/MPC3501 Fusing Unit	Athena C2.5	
Ricoh MPC3002/MPC3502 Fusing Unit	Athena C3	
Ricoh MPC3500/MPC4500 Fusing Unit	Apollo C1	
Ricoh MPC4000/MPC4500 Fusing Unit	Alex C1	
Ricoh MPC4000/MPC5000 Fusing Unit	Apollo C2	
Ricoh MPC4501/MPC5501 Fusing Unit	Apollo C2.5	
Ricoh MPC4502/MPC5502 Fusing Unit	Apollo C3	
Ricoh SP4000 Fusing Unit	Alex P1	
Ricoh SPC2800 Fusing Unit	Apollo P1	
Ricoh SPC4000 Fusing Unit	Apollo P2	
<b>MOBILE PHONES</b>		
<b>Mobile Phones</b>		
Most Makes**subject to age & condition		Most Models**
<b>INKJETS</b>		
<b>Brother</b>		
DCP-J132W Colour	LC123 KCMY	
DCP-J4110DW Colour	LC125XL KCMY	
MFC-J4110DW Hi-Cap Black	LC127XL	
DCP-J4120DW Colour	LC223 KCMY	
DPC-J4120DW Hi-Cap Colour	LC225XL CMY	
DCP-J4120DW Hi-Cap Black	LC227XL	
MFC-J5320DW Hi-Cap Black	LC229XL	
DCP-J6910 Colour	LC1240 KCMY	
MFC-J6510 Colour	LC1280 KCMY	
MFC-J6350 Colour	LC3217	
MFC-J6350	LC3219	
<b>Canon</b>		
B100/110/150 Fax	BX-3	
BJ200/230 Black	BC02	
Maxify MB5350 Colour	PGI-2500XL*	
Pixma IP1800/2500 Black	PG37/No.37	
Pixma IP1800/2500 Colour	CL38/No.38	
Pixma IP1600 Black Standard	PG40/No.40	
Pixma IP1600 Colour Standard	CL41/No.41	
Pixma IP1600 Black Hi-Cap	PG50/No.50	
Pixma IP1600 Colour Hi-Cap	CL51/No.51	
Pixma MP480/MP240/MP260 Black	PG510/No.510	
Pixma MP480/MP240/MP260 Black	previously recycled PG510/No.510	
Pixma MP480/MP240/MP260 Colour	CL511/No.511	
Pixma MP480/MP240/MP260 Colour	previously recycled CL511/No.511	
Pixma MP480/MP240/MP260 Black Hi-Cap	PG512/No.512	
Pixma MP480/MP240/MP260 Black Hi-Cap	previously recycled PG512/No.512	
Pixma MP480/MP240/MP260 Colour Hi-Cap	CL513/No.513	
Pixma MP480/MP240/MP260 Colour Hi-Cap	previously recycled CL513/No.513	
Pixma MG3150 Black Standard	PG540/No.540	
Pixma MG3150 Black Standard	previously recycled PG540/No.540	
Pixma MG3150 Colour Standard	CL541/No.541	
Pixma MG3150 Colour Standard	previously recycled CL541/No.541	
Pixma MG3150 Black High Cap	PG540XL/No.540XL	
Pixma MG3150 Black High Cap	previously recycled PG540XL/No.540XL	
Pixma MG3150 Colour High Cap	CL541XL/No.541XL	
Pixma MG3150 Colour High Cap	previously recycled CL541XL/No.541XL	
Pixma IP7250 Black	PG650/No.550	
Pixma IP7250 Hi-Cap Black	PG650XL/No.550XL	
Pixma IP7250 Extra Hi-Cap Black	PG655XL/No.555XL	
Pixma IP7250 Colour	CL551/No.551	
Pixma IP7250 Hi-Cap Colour	CL551XL/No.551XL	
Pixma M32550 Black Standard	PG545/No.545	
Pixma M32550 Colour Standard	CL546/No.546	
Pixma M32550 Black High Cap	PG545XL/No.545XL	
Pixma M32550 Black High Cap	previously recycled PG545XL/No.545XL	
Pixma M32550 Colour High Cap	CL546XL/No.546XL	
Pixma M32550 Colour High Cap	previously recycled CL546XL/No.546XL	
<b>Dell</b>		
V105 Series 15 Black	WP322	
V105 Series 15 Colour	UK852	
<b>Epson</b>		
Alarm Clock Series (27/27XL)	T27014-T27914	
Apple Series	T1291-T1294	
Big Ben Pyramid/Eiffel Tower Series	T7011-14/T7021-23/T7031-33	
Daisy Series (18/18XL)	T1801-T1814	
Fox Series	T1281-T1284	
Golf Ball (34/34XL)	T3461-T3474	
Orange Series (33/33XL)	T3331-T3364	
Padlock (35/35XL)	T3981-T3994	
Pen Series (16/16XL)	T1621-T1634	
Pro 3800 Series	T5801-5809	
Pro 4900 Series (200ml)	T6531-T6539	
Pro 6000 Series (Hi Cap and Extra High Cap)	T9081-T9084 / T9071-T9074	
Pro 7700 Series (700ml)	T8361-T8369	
Pro 7700 Series (350ml)	T5961-T5969	
Pro 8000 Series (350ml)	T7551-T7554	
Strawberry Series (29/29XL)	T2991-T2984	
SureColour SC-P6000/9000 (350 ml)	T8241-T8249	
UltraChrome P Series P9000	T8041-T8049	

Printer, Fax or Copier Type	Cartridge Part Number	Notes
HP		
DeskJet 810/840/843 Black	C6515A/D.No.15	
DeskJet 810/840/843 Black	previously recycled C6615A/D.No.15	
DeskJet 840/843 Colour	C6625A.No.17	
DeskJet 3920/3940/1410 Black	C9351A.No.21	
DeskJet 3920/3940/1410 Hi-Cap Black	C93510.No.21XL	
DeskJet 3920/3940/1410 Colour	previously recycled C9351A.No.21	
DeskJet 3920/3940/1410 Hi-Cap Colour	C9352A.No.22	
DeskJet 3920/3940/1410 Hi-Cap Colour	C9352C.No.22XL	
DeskJet 3920/3940/1410 Colour	previously recycled C9352A.No.22	
DeskJet 500/520/540 Black	5165A.No.26	
DeskJet 3320/3325/3420/3550 Black	C8727A.No.27	
DeskJet 3320/3325/3420/3550 Colour	previously recycled C8727A.No.27	
DeskJet 3320/3325/3420/3550 Colour	C8728A.No.28	
DeskJet 3320/3325/3420/3550 Colour	previously recycled C8728A.No.28	
DesignJet Z2100/Z2100	C9390/C9449/C9450/95A.No.70	
DesignJet 1610/1620/1770/1790	CS371-74A/C9403A.No.72	
DeskJet 1200C Black	51640A.No.40	
DesignJet 300/400/700 Colour	51644C/MY.No.44	
DeskJet 710/720/820/850/870/890 Black	51645A/G.No.45	
DeskJet 710/720/820/850/870/890 Black	previously recycled 51645A/G.No.45	
DeskJet 420/ci/bi/5150/5550c/5552 Black	C6566A.No.56	
DeskJet 420/ci/bi/5150/5550c/5552 Black	previously recycled C6566A.No.56	
DeskJet 420/ci/bi/5150/5550c/5552 Small Black	C6566G.No.56SMALL	
DeskJet 420/ci/bi/5150/5550c/5552 Colour	C6567A.No.57	
DeskJet 420/ci/bi/5150/5550c/5552 Colour	previously recycled C6567A.No.57	
DeskJet 420/ci/bi/5150/5550c/5552 Small Colour	C6567G.No.57SMALL	
DeskJet 420/ci/bi/5150/5550c/5552 Colour	CB267A/CB269A.No.57	
DeskJet 420/ci/bi/5150/5550c/5552 Speciality Colour	CB278A.No.57+	
DeskJet 420/ci/bi/5150/5550c/5552 Photo	C6568A.No.58	
DeskJet 420/ci/bi/5150/5550c/5552 Grey	C9359A.No.59	
Envy 5640/5740/7640 Black	C2P04A.No.62	
Envy 5640/5740/7640 Hi-Cap Black	C2P05A.No.62XL	
Envy 5640/5740/7640 Colour	C2P06A.No.62	
Envy 5640/5740/7640 Hi-Cap Colour	C2P07A.No.62XL	
DeskJet 930/950/970/990/C55/85/95 Colour	CB277A/D / No.77 / C6578A.No.78	
DeskJet 930/950/970/990/C55/85/95 Colour	previously recycled C6578A/D.No.78	
DesignJet 1050C Cyan + Magenta	C4846A/C4872A/C4874A/C4874A.No.80	
DesignJet 5000	C4930A-35A.No.81	
DesignJet 800 Colour	C4911A/C4912A/C4913A.No.82	
DesignJet 4000/4020/4500/40520	Hi Cap Black (775ml) C5059A.No.90	
DesignJet 4000/4020/4500/40520	Hi Cap Colour CMY (400ml) C5061A/63A/65A.No.90	
DesignJet Z6100	C9464-71A.No.91	
DeskJet F4280 Black	CC640EE.No.300	
DeskJet F4280 Black	previously recycled CC640EE.No.300	
DeskJet F4280 Hi-Cap Black	CC641EE.No.300XL	
DeskJet F4280 Hi-Cap Black	previously recycled CC641EE.No.300XL	
DeskJet F4280 Colour	CC643EE.No.300	
DeskJet F4280 Colour	previously recycled CC643EE.No.300	
DeskJet F4280 Hi-Cap Colour	CC644EE.No.300XL	
DeskJet F4280 Hi-Cap Colour	previously recycled CC644EE.No.300XL	
DeskJet 1050/2050 Black Old Gen	casing dated pre 07/2014 CH561EE.No.301	
DeskJet 1050/2050 Black New Gen	casing dated post 07/2014 CH561EE.No.301	
DeskJet 1050/2050 Black	previously recycled CH561EE.No.301	
DeskJet 1050/2050 Colour Old Gen	casing dated pre 07/2014 CH562EE.No.301	
DeskJet 1050/2050 Colour New Gen	casing dated post 07/2014 CH562EE.No.301	
DeskJet 1050/2050 Colour	previously recycled CH562EE.No.301	
DeskJet 1050/2050 Hi-Cap Black Old Gen	casing dated pre 07/2014 CH563EE.No.301XL	
DeskJet 1050/2050 Hi-Cap Black New Gen	casing dated post 07/2014 CH563EE.No.301XL	
DeskJet 1050/2050 Hi-Cap Black	previously recycled CH563EE.No.301XL	
DeskJet 1050/2050 Hi-Cap Colour Old Gen	casing dated pre 07/2014 CH564EE.No.301XL	
DeskJet 1050/2050 Hi-Cap Colour New Gen	casing dated post 07/2014 CH564EE.No.301XL	
DeskJet 1050/2050 Hi-Cap Colour	previously recycled CH564EE.No.301XL	
DeskJet 2130/3630 OfficeJet 3830/4650 Black	FU66AE.No.302	
DeskJet 2130/3630 OfficeJet 3830/4650 Colour	FU65AE.No.302	
DeskJet 2130/3630 OfficeJet 3830/4650 Hi-Cap Black	FU68AE.No.302XL	
DeskJet 2130/3630 OfficeJet 3830/4650 Hi-Cap Colour	FU67AE.No.302XL	
Envy Photo 6230/6234/7130/7134/7830 Black	T6N02AE.No.303	
Envy Photo 6230/6234/7130/7134/7830 Colour	T6N01AE.No.303	
Envy Photo 6230/6234/7134/7830 Hi-Cap Black	T6N04AE.No.303XL	
Envy 6230/6234/7130/7134/7830 Hi-Cap Colour	T6N03AE.No.303XL	
DeskJet 2632/3720/3732 Black	N9K06AE.No.304	
DeskJet 2632/3720/3732 Colour	N9K05AE.No.304	
DeskJet 2632/3720/3732 Hi-Cap Black	N9K08AE.No.304XL	
DeskJet 2632/3720/3732 Hi-Cap Colour	N9K07AE.No.304XL	
DeskJet 5420/5432/5442 Colour	C9361E.No.342	
DeskJet 5420/5432/5442 Colour	previously recycled C9361E.No.342	
DeskJet 5740/6520/6540/6540dt/6840 Color	C8766E.No.343	
DeskJet 5740/6520/6540/6540dt/6840 Color	previously recycled C8766E.No.343	
DeskJet 5740/6520/6540/6540dt/6840 Hi-Cap Colour	C9363E.No.344	
DeskJet 5740/6520/6540/6540dt/6840 Hi-Cap Colour	previously recycled C9363E.No.344	
DeskJet 5740/6520/6540/6540dt/6840 Photo	C9369E.No.348	
DeskJet D4260 OfficeJet J5780 Hi-Cap Black	CB336EE.No.350XL	
DeskJet D4260 OfficeJet J5780 Hi-Cap Black	previously recycled CB336EE.No.350XL	
DeskJet D4260 OfficeJet J5780 Colour	CB337EE.No.351	
DeskJet D4260 OfficeJet J5780 Hi-Cap Colour	CB338EE.No.351XL	
DeskJet D4260 OfficeJet J5780 Hi-Cap Colour	previously recycled CB338EE.No.351XL	
Photosmart 5510/6520/B109	No.364	
Photosmart 5510/6520/B109 Hi-Cap	No.364XL	
DeskJet 2510 Black	CZ101A.No.650	
DeskJet 2510 Colour	CZ102A.No.650	
DeskJet 5575/5645 Black	C2P10AE.No.651	
DeskJet 5575/5645 Colour	C2P11AE.No.651	
DeskJet 1115/2135/3635/3775/4535/5275	F6V25AE.No.652	
DeskJet 1115/2135/3635/3775/4535/5275	F6V24AE.No.652	
OfficeJet J4580/J4660/J4680 Black	previously recycled CC656A.No.901XL	
OfficeJet J4580/J4660/J4680 Colour	CC656A.No.901	
OfficeJet J4580/J4660/J4680 Colour	previously recycled CC656A.No.901	
OfficeJet Pro 6960/6970	T6L87/91/95/99AE.No.903	
OfficeJet Pro 6960/6970 Hi-Cap	T6M03/07/11/15AE.No.903XL	
OfficeJet Pro 6960/6970 Super Hi-Cap	T6M19AE.No.907XL	
OfficeJet 6500/7000 Hi-Cap Black	CD975A.No.920XL	
OfficeJet 6500/7000 Standard Black	CD971A.No.920	
OfficeJet 6500/7000 Colour	CD972A-74A.No.920	
OfficeJet 6100/660/6700 Hi-Cap Black	CN653A.No.932XL	
OfficeJet 6100/660/6700 Hi-Cap Colour	CN054A-056A.No.933XL	
OfficeJet Pro 6830 Black	C2P19A.No.934	
OfficeJet Pro 6830 Hi-Cap Black	C2P23A.No.934XL	
OfficeJet Pro 6830 Colour	C2P20A/21A/22A.No.935	
OfficeJet Pro 6830 Hi-Cap Colour	C2P24A/25A/26A.No.935XL	
OfficeJet 8100/8600 Hi-Cap Black	CN045AE.No.950XL	
OfficeJet 8100/8600 Hi-Cap Colour	CN046AE-48AE.No.951XL	
OfficeJet Pro 7720/8720 Black	LO558AE.No.953	
OfficeJet Pro 7720/8720 Colour	F6U12/13/14AE.No.953	
OfficeJet Pro 7720/8720 Hi-Cap Black	LO570AE.No.953X	
OfficeJet Pro 7720/8720 Hi-Cap Colour	F6U16/17/18AE.No.953X	
OfficeJet Pro X451/X476 Black	CN621A.No.970	
OfficeJet Pro X451/X476 Black	CN625A.No.970XL	
OfficeJet Pro X451/X476 Colour	CN622-624A.No.971	
OfficeJet Pro X451/X476 Hi-Cap Colour	CN626-628A.No.971XL	
PageWide Pro 477DW Black	LDR95AE.No.913A	
PageWide Pro 477DW Colour	F6T77/78/78AE.No.913A	
PageWide Pro 477DW Hi-Cap Black	LO507AE.No.973X	

Printer, Fax or Copier Type	Cartridge Part Number	Notes
<b>HP (cont.)</b>		
PageWide Pro 477DW Hi-Cap Colour	F6T81/82/83AE/No.973X	
PageWide Pro 750/772/777 Black	M0J86AE /No.991A	
PageWide Pro 750/772/777 Colour	M0J74/78/82AE/No.991A	
PageWide Pro 750/772/777 Hi-Cap Black	M0K02A/No.991X	
PageWide Pro 750/772/777 Hi-Cap Colour	M0J90/94/98AE/No.991X	
OfficeJet X555/X585 Series Colour	DBJ07-10A/No.980	
Black Dye 1918 Specialist Inkjet	Q2344A	
Versatile Black	C8842A	
Fast Dry Black	C6195A	
Non Fluorescent Red	C6126A	
Spot Colour Blue	C6170A	
Non Fluorescent Red	CG400A	
Blue Pigment	CG401A	
<b>Lexmark</b>		
4076/WW 150 Black	13400HC	
X2350 Black	18C0781E/No.1	
X2580/3580/Z1380 Colour	18C0190E/No.2	
X2580/3580/Z1380 Black	18C1530E/No.3	
Jetprinter i3/Z13/Z23/Z33/Z601/Z605 Black	10N0016/No.16/10N0217/No.17	
Jetprinter Z815/X5250/5270 Colour	18C0035E/No.33	
Jetprinter Z815/X5250/5270 Black	18C0034E/No.34	
Jetprinter Z815/X5250/5270 Black	previously recycled 18C0034E/No.34	
Jetprinter Z815/X5250/5270 Colour	18C0035E/No.35	
Jetprinter Z815/X5250/5270 Colour	previously recycled 18C0035E/No.35	
<b>Neopost</b>		
U25	U25	
U25	previously recycled U25	
U90	U90	
U35/40/45/50/65/75/85	U35/40/45/50/65/75/85	
U35/40/45/50/65/75/85	previously recycled U35/40/45/50/65/75/85	
IS350/420/480	IS350/420/480	
IS350/420/480	previously recycled IS350/420/480	
<b>Samsung</b>		
SF330/335	Ink M40	
SF370	Ink M41	